User manual



BAR LED 12X15W RGBW




Please read carefully before use

Please Note: Specifications and improvements in the design of this unit and this manual are subject to change without any prior written notice.

Product Overview





RDM---Remote Device Management

RDM is a wild version of the DMX512-A protocol, allowing dimming stations and other control devices to be discovered through a DMX512 network, and then configuring, status monitoring, and managing intermediate and line end devices.


It allows two-way communication between the lighting device or system controller and the connected RDM compatible device through the standard DMX. This protocol will allow these devices to be configured, monitored, and managed in a manner that does not interfere with the normal operation of standard DMX512 devices that do not recognize the RDM protocol.

Allow a controller or test device to find other devices that can be RDM, such as computer lights or dimming cabinets, and remotely manage them through this connection intelligence. Including the ability to remotely set the initial address of the DMX512, query the device's errors or statistics, and achieve most of the configuration settings that are usually done on the front panel of the device. RDM can run with the new RDM device or any original DMX512 product on the same data link without any performance impact. Since RDM runs on the first team DMX512 link, the only infrastructure upgrade required by RDM is to upgrade the existing data distributor to implement a two-way mode to support RDM.

The RDM information is transmitted through the first pair of DMX512 data channels. RDM uses packets that include non-zero initial codes to start and control communications. This alternating(rotating) session and waiting for indicative responses is performed in a semi-duplex format. The second data pair is not used for any RDM function.


Two-way data transmission-each vendor's equipment can exchange data, Art-net can only transmit data, can not exchange with each other.

Its functions are as followed:



Mechanical Specification


IR Controller





- Power on/off button
- DMX button, to control DMX address when press this button.
- Master-slave mode button.
- Automatic mode button
- Speed adjustive button
- Up and down button, you can choose the program that you need or numerical.
- Strobe button
- 0 1 2 3 4 ⁵ _w 6 **7**

You can use these number button to adjust numerical in any program mode.









Packaging: All the lights have been checked and are in excellent operating condition. Please check the shipping carton first. Because there may be damage that occurred during the shipment. Then check the lights carefully and be sure that the light is intact and works normally. In the event damage has been found, spare parts are missing, or the lights work abnormally, please contact us for further instructions. And please don't return the light to the dealer before contacting us.

Introduction: four operating modes: DMX mode, Auto mode, Master/Slave mode. And the light has seven DMX channels. DMX channel includes 3 channels, 7 channels, 11 channel, 48 channel and 52 channel. You can see 13 kinds of shows when you open Auto mode. All then all the lights in Master/Slave mode will run following the one in Auto mode. Using fog or special effect smoke, you can see better showing effect.


Warning!

- 1. For the sake of preventing the risk of electrical shock or fire.
- 2. Don't look directly at the opening lights all the time, or it may damage your eyes.

CABLE CONNECTORS

Cabling must have a male XLR connector on one end and a female XLR connector on the other end

DMX connector configuration



caution: Do not allow contact between the ground and the fixture's chassis ground. Grounding the ground can cause a ground loop, and your fixture may perform erratically. Test cables with an ohm meter to verify positive pole and to make sure the pins are not grounded or shorted to the shield or each other

3-PIN TO 5-PIN CONVERSION CHART

Note! If you use a controller with a 5 pin DMX output connector, you need to use a 5 pin to 3 pin adapter. The chart below details a proper cable conversion:

3-PIN TO 5-PIN CONVERSION CHART


Conductor	3 Pin Female (output)	5 Pin Male (Input)
Ground/Shield	Pin 1	Pin 1
Data (-) signal	Pin 2	Pin 2
Data (+) signal	Pin 3	Pin 3
Do not use		Do not use
Do not use		Do not use

Mounting

When installing the unit, the trussing or area of installation must be able to hold 10 times the weight without any deformation. When installing the unit must be secured with a secondary safety attachment, e.g. and appropriate safety cable. Never stand directly below the unit when mounting, removing, or servicing the unit.

Overhead mounting requires extensive experience, including calculating working load limits, installation material being used, and periodic safety inspection of all installation material and unit. If you lack these qualifications, do not attempt the installation yourself.

The installation should be checked by a skilled person once a year.



The AH019A is fully operational in three different mounting positions, hanging upside-down from a ceiling, set on a flat level surface or mount the unit on its side. Be sure this fixture is kept at least 0.5m away from any flammable materials (decoration etc.). And you'd better use and install the supplied safety cable as a safety measure to prevent accidental damage and/or injury in the event the clamp fails (see next page).

Features


- Light Source: 12*15W, 4 in 1 RGBW LEDs
- Lens:10*45°/8°/25°/40°
- Power consumption: 160W
- Voltage: AC 110-230V 50/60Hz
- Run mode: DMX 512 /Master Slave /Auto Run
- DMX channels: 3, 7, 11, 48 & 52 CH
- Built-in Effect: color mixing, variable color chasing, strobing and fading.
- Fan controlled by PWM waves.
- 4 dimmer curves
- TFT displayer with four buttons
- Material: Aluminum body
- IP65
- Temperature: -20°C ~ 40°C
- Dimension:1017x140x216mm
- N.W: 9.1 KGG.W: 10.4KG

Accessory


- ① Barndoor x 1 (purchase separate)
- ④ DMX cable x1
- (2) Frost filter x 1 (purchase separate)
- (5) User manual x 1

3 Power cable x 1

⑥ IR Controller x 1



Displayer introduction



- 1. DMX means the light is in the DMX mode. Similarly, SLAVE means the light is in the SLAVE mode.
- 2. The color of the point shows the condition of signal transmission. Green represents the good condition, while red represents the signal is interrupted.
- 3. The item shows the working temperature of the light. When the working temperature exceeds the max temperature, the color of the letters and number will change from white to yellow.
- 4. This item shows the menu you selected.
- 5. This item shows the condition of key lock. "Key lock open" means the key lock is open. And "Key lock off" means the key lock is close.

CCT-In this menu, you can choose the brightness you desired.

- 1. Press "ENTER" and then press "UP" or "DOWN" to "CCT".
- 2. Press "ENTER" you can choose from "2700K" to "8000K" as you need.

SET UP-In this menu, you can adjust the values of the function.

- 1. Press "ENTER" and then press "UP" or "DOWN" to "SET UP".
- 2. Press "ENTER" and there has 6 options, then press "UP" or "DOWN" to choose the value you desired as below:
- 1) IR You can press "ON" or "OFF" to choose whether you need to control by this mode.
- 2) Dimmer All You can adjust the brightness of colors.
- 3) White Balance You can select "RED" "GREEN" "BLUE" "WHITE" you need.
- 4) Key Lock You can choose "5s" or "OFF" to make the Key Lock turn on or off.
- 5) Display You can choose "ON" or "30s" to make the position of the light screen.
- 6) Max temp You can set the your desired Max working temperature of the light with passcode in this menu. When the working temperature beyond max temperature of default settings, the color of letter "Temp XX" will show the color from white to yellow. Meanwhile, the light will adjust the working temperature automatically.

INFORMATION-In this menu, you can learn about the information of RDM, software, hardware and working time of the light.

- 1. Press "ENTER" and then press "UP" or "DOWN" to "INFORMATION".
- 2. Press "ENTER" and you can see 3 items as below:
- 1) RDM It shows RDM information.
- 2) Hardware It shows the Hardware information.
- 3) Software It shows the Software information.
- 4) Working time It shows the working time information.

FACTORY RESET-In this menu, you can reset all the value of the system.

- 1. Press "ENTER" and then press "UP" or "DOWN" to "FACTORY RESET".
- 2. Press "ENTER" and enter the passcode to reset all the values of the system.

WIRELESS-In this menu, you can set the Wireless signal.

- 1. Press "ENTER" and then press "UP" or "DOWN" to "WIRELESS".
- 2. Press "ENTER" and then choose "ON" or "OFF" to set the Wireless signal. "ON" is turn on the signal and "OFF" is turn off the signal.

DMX MODE-In this menu, you can connect several pieces of lights with DMX cable and control them with the control console.

Press" ENTER" and then press "UP" or "DOWN" to "Address" or "DMX Channel" and press "ENTER".

- 1) "XXX" will be showed in "Address", "XXX" means the Address 001-512. You can press "UP" or "DOWN "to select the address you desired.
- 2) "Channel [xx]" will be showed in "DMX Channels", "XX" means 5 kinds of DMX Channels Modes. You can press "UP" or "DOWN" to select the Channel Mode you desired.

DIMMER CURVE-In this menu, you can choose the mode you desired.

- 1. Press" ENTER" and then press "UP" or "DOWN" to "Dimmer Curve" to choose as below modes.
- 2. Press "ENTER" you can see 4 items as below:
- 1) Standard
- 2) Stage/TV
- 3) Architect
- 4) Theatre

DMX STATE-In this menu, you can choose the DMX signal you desired.

- 1. Press "ENTER" and then press "UP" or "DOWN" to "DMX STATE".
- 2. Press "ENTER" and you can choose "Blackout" or "DMX Hold" ; "Blackout" means cut off the DMX signal and "DMX Hold" means connect DMX signal.

SLAVE MODE-In this menu, you can choose one light as the MASTER light and other lights in SLAVE Mode will run follow the MASTER light.

- 1. Press "ENTER" and then press "UP" or "DOWN" to "SLAVE Mode".
- 2. Press "ENTER" and "SLAVE" will be showed, then press "ENTER" to choose.


AUTO MODE-In this menu, you can choose your desired AUTO Mode and adjust the running speed.

- 1. Press "ENTER" and then press "UP" or "DOWN" to "AUTO MODE".
- 2. Press "ENTER" you can see 2 items as below:
- 1) SPEED It provides "01-31" for you choose.
- 2) AUTO MODE It provides "AUTO 1- AUTO 13" for you choose.

STATIC COLOR-In this menu, you can choose the modes you need.

- 1. Press "ENTER" and then press "UP" or "DOWN" to "AUTO MODE".
- 2. Press "ENTER" you can see 6 items as below:
- 1) RED
- 2) GREEN
- 3) BLUE
- 4) WHITE
- 5) COLOR You can choose "1-63" in this menu.
- 6) STROBE You can choose "0-20" in this menu.

Program Menu




UPLOAD



First, set one light, which involves the program you have edited in EDIT menu and want to upload, in Master mode, and others in Slave mode.

Then, connect all the lights with DMX cables. Finally, select the UPLOAD menu of the Master light and press ENTER. All the programs edited in the Master light will be uploaded to the Slave lights.



	41	0 - 255	Red
	42	0 - 255	Green
	43	0 - 255	Blue
	44	0 - 255	White
52CH	45	0 - 255	Red
	46	0 - 255	Green
	47	0 - 255	Blue
	48	0 - 255	White
	49	0 - 255	Red
	50	0 - 255	Green
	51	0 - 255	Blue
	52	0 - 255	White

DMX control mode

зсн	Channel	Value	Function
	1	0-255	Hue
	2	0-255	Saturation
	3	0-255	Value (Brightness)
	1	0-255	Master Dimming (0~100%)
	2	0-255	Dimmer curve
	3	0-255	Red dimmer
7CH	4	0-255	Green dimmer
	5	0-255	Blue dimmer
	6	0-255	White dimmer
	7	0-255	Strobe
	1	0-255	Master Dimming (0~100%)
	2	0-255	Dimmer curve
	3	0-255	Red dimmer
	4	0-255	Green dimmer
	5	0-255	Blue dimmer
	6	0-255	White dimmer
	7	0-255	Strobe
	8	0-7	none
		8-255	Marco Color
	9	0-255	CCT
		0 - 8	none
		9 - 27	auto 1
11CH		28 - 47	auto 2
		48 - 67	auto 3
		68 - 87	auto 4
		88 - 107	auto 5
		108 -127	auto 6
	10	128 - 147	auto 7
		148 - 167	auto 8
		168 - 187	auto 9
		188 - 207	auto 10
		208 - 227	auto 11
		228 - 247	auto 12
		248 - 255	auto 13
	11	0 - 255	Speed
	L		-1

	1	0 - 255	Red
	2	0 - 255	Green
	3	0 - 255	Blue
	4	0 - 255	White
	5	0 - 255	Red
	6	0 - 255	Green
	7	0 - 255	Blue
	8	0 - 255	White
	9	0 - 255	Red
	10	0 - 255	Green
	11	0 - 255	Blue
	12	0 - 255	White
	13	0 - 255	Red
	14	0 - 255	Green
	15	0 - 255	Blue
	16	0 - 255	White
	17	0 - 255	Red
	18	0 - 255	Green
	19	0 - 255	Blue
48CH	20	0 - 255	White
	21	0 - 255	Red
	22	0 - 255	Green
	23	0 - 255	Blue
	24	0 - 255	White
	25	0 - 255	Red
	26	0 - 255	Green
	27	0 - 255	Blue
	28	0 - 255	White
	29	0 - 255	Red
	30	0 - 255	Green
	31	0 - 255	Blue
	32	0 - 255	White
	33	0 - 255	Red
	34	0 - 255	Green
	35	0 - 255	Blue
	36	0 - 255	White
	37	0 - 255	Red
	38	0 - 255	Green
	39	0 - 255	Blue
	40	0 - 255	White
	41	0 - 255	Red
	42	0 - 255	Green
	43	0 - 255	Blue
	44	0 - 255	White
	1 ''	0 200	***************************************

	1 45	0.055	
48CH	45	0 - 255	Red
	46	0 - 255	Green
	47	0 - 255	Blue
	48	0 - 255	White
	1	0 - 255	Master Dimming (0~100%)
	2	0 - 255	Dimmer curve
	3	0 - 255	Auto
	4	0 - 255	Speed
	5	0 - 255	Red
	6	0 - 255	Green
	7	0 - 255	Blue
	8	0 - 255	White
	9	0 - 255	Red
	10	0 - 255	Green
	11	0 - 255	Blue
	12	0 - 255	White
	13	0 - 255	Red
	14	0 - 255	Green
	15	0 - 255	Blue
	16	0 - 255	White
	17	0 - 255	Red
	18	0 - 255	Green
52CH	19	0 - 255	Blue
32011	20	0 - 255	White
	21	0 - 255	Red
	22	0 - 255	Green
	23	0 - 255	Blue
	24	0 - 255	White
	25	0 - 255	Red
	26	0 - 255	Green
	27	0 - 255	Blue
	28	0 - 255	White
	29	0 - 255	Red
	30	0 - 255	Green
	31	0 - 255	Blue
	32	0 - 255	White
	33	0 - 255	Red
	34	0 - 255	Green
	35	0 - 255	Blue
	36	0 - 255	White
	37	0 - 255	Red
	38	0 - 255	Green
	39	0 - 255	Blue
	40	0 - 255	White
	40	0 - 200	AALIIIC