


User instructions

ArcSource 4 MC

The module generates colored light by means of RGBW LED multichip. The product was designed to use with the ArcPower driver and for indoor use only.



1. Attention

- Do not install the module near high inflammable liquids or materials.
- Do not allow anything to rest on the module.
- Do not use the module near high humidity or water or expose to the rain.
- Do not install the module near the naked flames.
- Do not install the module in dirty, dusty or badly ventilated location.
- Sufficient air accessing to the cooling ribs of the module housing has to be ensured.**
- Use the standard MR16 fittings to fix the modules on a suitable place.

2. Installation

The ArcSource 4 MC unit has to be connected to the power source of type of LVLE according to the specifications stated in the chapter "Technical specifications"..

CAUTION!
Avoid looking directly into the LED light beam at close range!

3. RJ45 pin connection



